






**可動用 LED**  
**⑬363,⑭370,⑮377,⑯384**




**可動用 ストロボ**  
③405,④407,⑤409,⑥411



新宿BLAZE

2019年 1月23日 現在





新宿BLAZE

2019年 1月23日 現在



PAR64  
500W Nx60 (可動用x14)

PAR64  
500W Mx32 (可動用x8)

PAR64  
500W VN x16 (可動用x8)

FQ  
500W x9 (可動用x5)  
客電除く

2MOLE  
300W x8 (可動用x4)

Source Four 436  
750W x9 (可動用x3)

LED PARx20 (可動用x4)

可動用 LED  
①7 413, ①8 420, ①9 427, ②0 434

ストロボx6 (可動用x4)


可動用 ストロボ  
③ 205, ④ 207, ⑤ 209, ⑥ 211

ミラーボール

60A/No 100V/60A


D/No 200V/20A

4PN 4ポートノード



新宿BLAZE





新宿BLAZE



|         |         |             |          |        |             |            |               |       |                |    |
|---------|---------|-------------|----------|--------|-------------|------------|---------------|-------|----------------|----|
| 1       | 2       | 3           | 4        | 5      | 6           | 7          | 8             | 9     | 10             |    |
| 86      | #W      |             |          | Side#W |             |            | #W            |       |                | 22 |
| 003/009 | 042     | 051         | 028      | 033    | 038         | 053        | 020           | 017   | 029            |    |
| 11      | 12      | 13          | 14       | 15     | 16          | 17         | 18            | 19    | 20             |    |
| 22      |         |             | 77       |        |             |            |               |       | Side#78        |    |
| 2       | 3       | 4           | 1        | 2      | 3           | 4          | 5             | 6     | 下              |    |
| 032     | 025     | 036         | 045      | 048    | 026         | 035        | 016           | 021   | 037            |    |
| 21      | 22      | 23          | 24       | 25     | 26          | 27         | 28            | 29    | 30             |    |
| Side#78 | 31      |             |          |        | 2MOLE       |            |               |       |                |    |
| 上       | 1       | 2           | 3        | 4      | 1           | 2          | 3             | 4     | Wx1            |    |
| 054     | 041     | 052         | 014      | 023    | 001         | 005        | 006           | 011   | 031            |    |
| 31      | 32      | 33          | 34       | 35     | 36          | 37         | 38            | 39    | 40             |    |
| SF      |         |             | CL SF    |        |             |            |               |       |                |    |
| 1       | 2       | 3           | 4        | 5      | 6           | 1          | 2             | 3     |                |    |
| 013     | 019     | 024         | 027      | 030    | 034         | 084        | 085           | 086   |                |    |
| 41      | 42      | 43          | 44       | 45     | 46          | 47         | 48            | 49    | 50             |    |
| CL      |         | 前SS#W       |          | 奥SS#W  |             |            |               |       |                |    |
| 71      | 84      | 22          | N/C      | 下      | 上           | 下          | 上             |       |                |    |
| 099/102 | 098/101 | 90/92/94/96 | 91/93/95 | 057    | 061         | 065        | 069           |       |                |    |
| 51      | 52      | 53          | 54       | 55     | 56          | 57         | 58            | 59    | 60             |    |
|         |         |             |          |        | MB<br>moter | MB<br>lamp | work<br>light | smoke | house<br>light |    |
|         |         |             |          |        | 401         |            | 068/072       | 302   | 81/89/97       |    |
| 61      | 62      | 63          | 64       | 65     | 66          | 67         | 68            | 69    | 70             |    |
| Spikie  |         |             |          |        |             |            |               |       |                |    |
| 1       | 2       | 3           | 4        | 5      | 6           | 7          | 8             |       |                |    |
| 001     | 028     | 055         | 082      | 109    | 136         | 163        | 190           |       |                |    |
| 71      | 72      | 73          | 74       | 75     | 76          | 77         | 78            | 79    | 80             |    |
| Strobe  |         |             | L Par-7  |        |             |            |               |       |                |    |
| 1       | 2       | 3           | 4        | 5      | 6           | 1          | 2             | 3     | 4              |    |
| 401     | 403     | 405         | 407      | 409    | 411         | 451        | 459           | 467   | 475            |    |
| 81      | 82      | 83          | 84       | 85     | 86          | 87         | 88            | 89    | 90             |    |
|         |         |             |          |        |             |            |               |       |                |    |
| 91      | 92      | 93          | 94       | 95     | 96          | 97         | 98            | 99    | 100            |    |
| LED Par |         |             |          |        |             |            |               |       |                |    |
| 1       | 2       | 3           | 4        | 5      | 6           | 7          | 8             | 9     | 10             |    |
| 251     | 258     | 265         | 272      | 279    | 286         | 293        | 300           | 307   | 314            |    |
| 101     | 102     | 103         | 104      | 105    | 106         | 107        | 108           | 109   | 110            |    |
| LED Par |         |             |          |        |             |            |               |       |                |    |
| 11      | 12      | 13          | 14       | 15     | 16          | 17         | 18            | 19    | 20             |    |
| 321     | 328     | 335         | 342      | 349    | 356         | 363        | 370           | 377   | 384            |    |
| 111     | 112     | 113         | 114      | 115    | 116         | 117        | 118           | 119   | 120            |    |
|         |         |             |          |        |             |            |               |       |                |    |

FADER

|              |             |            |             |            |             |           |           |          |            |       |
|--------------|-------------|------------|-------------|------------|-------------|-----------|-----------|----------|------------|-------|
| 1            | 2           | 3          | 4           | 5          | 6           | 7         | 8         | 9        | 10         |       |
|              |             |            |             |            |             |           |           |          |            |       |
| W [3Mix]     | W           | P          | R           | Am         | L Am        | Y         | G         | LG       | C          |       |
| c            | c           | c          | c           | c          | c           | c         | c         | c        |            |       |
|              |             |            |             |            |             |           |           |          |            |       |
| 11           | 12          | 13         | 14          | 15         | 16          | 17        | 18        | 19       | 20         |       |
|              |             |            |             |            |             |           |           |          |            |       |
| BG           | LB          | B          | DB          | Pu         | M           | Lv        | L Lv      | CTB      | CTO        |       |
| c            | c           | c          | c           |            |             |           |           |          |            |       |
|              |             |            |             |            |             |           |           |          |            |       |
| 21           | 22          | 23         | 24          | 25         | 26          | 27        | 28        | 29       | 30         |       |
| Dim 0        | Dim 30      | Dim 50     | Dim 70      | Dim 100    | Strobe Open | Sync Low  | Sync High | Rnd Low  | Rnd High   |       |
| Dim          | Dim         | Dim        | Dim         | Dim        | シャッター       | シャッター     | シャッター     | シャッター    | シャッター      |       |
|              |             |            |             |            |             |           |           |          |            |       |
| 31           | 32          | 33         | 34          | 35         | 36          | 37        | 38        | 39       | 40         |       |
| home         | straight    | cross      | fan         | vo         | aud hi      | aud low   | aud Rnd   | 目潰し      |            |       |
| Position     | Position    | Position   | Position    | Position   | Position    | Position  | Position  | Position | Position   |       |
|              |             |            |             |            |             |           |           |          |            |       |
| 41           | 42          | 43         | 44          | 45         | 46          | 47        | 48        | 49       | 50         |       |
| Effect OPEN  | <<<<        | <<<        | <<          | <          | Rot Stop    | >         | >>        | >>>      | >>>>       |       |
| Effect       | Effect      | Effect     | Effect      | Effect     | Effect      | Effect    | Effect    | Effect   | Effect     |       |
|              |             |            |             |            |             |           |           |          |            |       |
| 51           | 52          | 53         | 54          | 55         | 56          | 57        | 58        | 59       | 60         |       |
| Prizm OPEN   | <<<<        | <<<        | <<          | <          | Rot Stop    | >         | >>        | >>>      | >>>>       |       |
| Effect       | Effect      | Effect     | Effect      | Effect     | Effect      | Effect    | Effect    | Effect   | Effect     |       |
|              |             |            |             |            |             |           |           |          |            |       |
| 61           | 62          | 63         | 64          | 65         | 66          | 67        | 68        | 69       | 70         |       |
| Zoom Narrow  | Zoom Normal | Zoom Wide  |             |            |             |           | 2700K     | 4500K    | 6300K      | 8000K |
|              |             |            |             |            |             | Color     | Color     | Color    | Color      |       |
|              |             |            |             |            |             |           |           |          |            |       |
| 71           | 72          | 73         | 74          | 75         | 76          | 77        | 78        | 79       | 80         |       |
| ぐるぐる ALLStop | PAN <<<     | PAN <<     | PAN <       | PAN Stop   | PAN >       | PAN >>    | PAN >>>   |          |            |       |
|              |             |            |             |            |             |           |           |          |            |       |
| 81           | 82          | 83         | 84          | 85         | 86          | 87        | 88        | 89       | 90         |       |
| TILT <<<     | TILT <<     | TILT <     | TILT Stop   | TILT >     | TILT >>     | TILT >>>  |           |          |            |       |
| group        | group       | group      | group       | group      | group       | group     | group     | group    | group      |       |
|              |             |            |             |            |             |           |           |          |            |       |
| 91           | 92          | 93         | 94          | 95         | 96          | 97        | 98        | 99       | 100        |       |
| Spikie all   | Spikie Rnd  | Spikie odd | Spikie EVEN | Spikie 内～外 | Spikie 奥～前  |           |           |          | Strobe ALL |       |
| group        |             |            |             |            |             |           |           |          |            |       |
|              |             |            |             |            |             |           |           |          |            |       |
| 101          | 102         | 103        | 104         | 105        | 106         | 107       | 108       | 109      | 110        |       |
| LED all      | LED Rnd     | LED odd    | LED Even    | LED Even   | LED SUS     | LED Stage | 柱 染め      | LED 内～外  | LED 奥～前    |       |
| group        |             |            |             |            |             |           |           |          |            |       |
|              |             |            |             |            |             |           |           |          |            |       |
| 111          | 112         | 113        | 114         | 115        | 116         | 117       | 118       | 119      | 120        |       |
|              |             |            |             |            |             |           |           |          |            |       |

PALETTE

Dimmer

| Unit  | Cir | CH | Name     | Unit  | Cir | CH | Name     | Unit   | Cir | CH | Name     | Unit   | Cir | CH | Name     | Unit | Cir | CH | Name    |
|-------|-----|----|----------|-------|-----|----|----------|--------|-----|----|----------|--------|-----|----|----------|------|-----|----|---------|
| 1tr 下 | 1   | 26 | 2mole 下1 | 3tr 下 | 25  | 12 | #22-3    | 4tr 上  | 49  |    |          | ステージ下奥 | 73  |    |          | 客席下奥 | 97  |    |         |
|       | 2   |    |          |       | 26  | 16 | #77-3    |        | 50  |    |          |        | 74  |    |          |      | 98  | 42 | CL #84下 |
|       | 3   | 1  | #86 下×2  |       | 27  | 34 | SF-4     |        | 51  | 3  | #W-2     |        | 75  |    |          |      | 99  | 41 | CL #73下 |
|       | 4   |    |          |       | 28  | 4  | #W-3     |        | 52  | 23 | #31-2    |        | 76  |    |          |      | 100 |    |         |
| 1tr 中 | 5   | 27 | 2mole 下2 | 3tr 中 | 29  | 10 | #22-1    | クロス 上  | 53  | 7  | Side#W上  | ステージ上奥 | 77  |    |          | 客席上奥 | 101 | 42 | CL #84上 |
|       | 6   | 28 | 2mole 上2 |       | 30  | 35 | SF-5     |        | 54  | 21 | Side#78上 |        | 78  |    |          |      | 102 | 41 | CL #73上 |
|       | 7   |    |          |       | 31  | 30 | #W×1     |        | 55  |    |          |        | 79  |    |          |      | 103 |    |         |
|       | 8   |    |          |       | 32  | 11 | #20-2    |        | 56  |    |          |        | 80  |    |          |      | 104 |    |         |
| 1tr 上 | 9   | 1  | #86 下×2  | 3tr 上 | 33  | 5  | #W-4     | ステージ下前 | 57  | 45 | 前SS#W下   | 客席下前   | 81  | 60 | 客電(前1列)  |      |     |    |         |
|       | 10  |    |          |       | 34  | 36 | SF-6     |        | 58  |    |          |        | 82  |    |          |      |     |    |         |
|       | 11  | 29 | 2mole 上1 |       | 35  | 17 | #77-4    |        | 59  |    |          |        | 83  |    |          |      |     |    |         |
|       | 12  |    |          |       | 36  | 13 | #22-4    |        | 60  |    |          |        | 84  | 49 | CL/SF 下  |      |     |    |         |
| Unit  | Cir | CH | Name     | Unit  | Cir | CH | Name     | Unit   | Cir | CH | Name     | Unit   | Cir | CH | Name     |      |     |    |         |
| 2tr 下 | 13  | 31 | SF-1     | クロス 下 | 37  | 20 | Side#78下 | ステージ上前 | 61  | 46 | 前SS#W上   | 客席上前   | 85  | 50 | CL/SF 中  |      |     |    |         |
|       | 14  | 24 | #31-3    |       | 38  | 6  | Side#W下  |        | 62  |    |          |        | 86  | 51 | CL/SF 上  |      |     |    |         |
|       | 15  |    |          |       | 39  |    |          |        | 63  |    |          |        | 87  |    |          |      |     |    |         |
|       | 16  | 18 | #77-5    |       | 40  |    |          |        | 64  |    |          |        | 88  |    |          |      |     |    |         |
| 2tr 中 | 17  | 9  | #W-8     | 4tr 下 | 41  | 22 | #31-1    | ステージ下中 | 65  | 47 | 奥SS#W下   | 客席下中   | 89  | 60 | 客電(中1列)  |      |     |    |         |
|       | 18  |    |          |       | 42  | 2  | #W-1     |        | 66  |    |          |        | 90  | 43 | CL #22下1 |      |     |    |         |
|       | 19  | 32 | SF-2     |       | 43  |    |          |        | 67  |    |          |        | 91  | 44 | CL #W下   |      |     |    |         |
|       | 20  | 8  | #W-7     |       | 44  |    |          |        | 68  | 58 | 作業灯 下    |        | 92  | 43 | CL #22下2 |      |     |    |         |
| 2tr 上 | 21  | 19 | #77-6    | 4tr 中 | 45  | 14 | #77-1    | ステージ上中 | 69  | 48 | 奥SS#W上   | 客席上中   | 93  | 44 | CL #W上2  |      |     |    |         |
|       | 22  |    |          |       | 46  |    |          |        | 70  |    |          |        | 94  | 43 | CL #22上2 |      |     |    |         |
|       | 23  | 25 | #31-4    |       | 47  |    |          |        | 71  |    |          |        | 95  | 44 | CL #W上1  |      |     |    |         |
|       | 24  | 33 | SF-3     |       | 48  | 15 | #77-2    |        | 72  | 58 | 作業灯 上    |        | 96  | 43 | CL #22上1 |      |     |    |         |

直回路

| Unit   | Cir  | Add | Name     |     | Unit   | Cir    | Add     | Name     |  | Unit   | Cir    | Fader   | Name    |
|--------|------|-----|----------|-----|--------|--------|---------|----------|--|--------|--------|---------|---------|
| ステージ上奥 | D-1  |     |          |     | ステージ下奥 | 60AC-1 |         |          |  | ステージ下前 | 60AC-7 | 402,403 | MBあて    |
| ステージ下奥 | D-2  |     |          |     | ステージ上奥 | 60AC-2 |         |          |  |        |        |         |         |
| 4tr 上1 | D-3  | 190 | Spikie-8 |     | ステージ上前 | 60AC-3 | 402,403 | MBあて     |  | 客席前    | 60AC-8 |         |         |
| 4tr 上2 | D-4  |     |          |     |        |        |         |          |  | 客席奥    | 60AC-9 | 402,403 | MBあて    |
| 4tr 下2 | D-5  | 163 | Spikie-7 |     |        | 401    | MB      |          |  |        |        |         |         |
| 4tr 下1 | D-6  | 136 | Spikie-6 |     | 4tr    | 60AC-4 | 251     | Quad-1   |  | FOH    | 30AC   |         |         |
| ステージ上中 | D-7  |     |          |     |        |        | 258     | Quad-2   |  |        | 30AC   |         |         |
| 3tr 上1 | D-8  |     |          |     |        |        | 265     | Quad-3   |  |        | 20AC   |         |         |
| 3tr 上2 | D-9  | 109 | Spikie-5 |     |        |        | 272     | Quad-4   |  |        | 20AC   |         |         |
| 3tr 下2 | D-10 | 82  | Spikie-4 |     |        |        | 279     | Quad-5   |  |        | 20AD   |         |         |
| 3tr 下1 | D-11 | 55  | Spikie-3 |     |        |        | 286     | Quad-6   |  |        | 20AD   |         |         |
| ステージ下中 | D-12 |     |          |     |        |        | 293     | Quad-7   |  |        | 20AD   |         |         |
| 2tr 上  | D-13 | 28  | Spikie-2 |     |        |        | 300     | Quad-8   |  |        | 20AD   |         |         |
| 2tr 中  | D-14 |     |          |     | 3tr    | 60AC-5 | 401     | Strobe-1 |  |        | 20AD   |         |         |
| 2tr 下  | D-15 | 1   | Spikie-1 |     |        |        | 403     | Strobe-2 |  |        | 15A平   |         | 卓まわり    |
| 客席上前   | D-16 |     |          |     | 2tr    | 60AC-6 | 307     | Quad-9   |  |        | 15A平   |         |         |
| 客席下前   | D-17 |     |          |     |        |        | 314     | Quad-10  |  |        | 60AC   |         | PIN × 2 |
| 客席上奥   | D-18 |     |          |     |        |        | 321     | Quad-11  |  |        | 60AC   |         | 映像用電源   |
| 客席下奥   | D-19 |     |          |     |        |        | 328     | Quad-12  |  |        |        |         |         |
|        |      |     |          |     |        |        | 335     | Quad-13  |  |        |        |         |         |
|        |      |     |          |     |        |        | 342     | Quad-14  |  |        |        |         |         |
|        |      |     |          |     |        |        | 349     | Quad-15  |  |        |        |         |         |
|        |      |     |          | 356 |        |        | Quad-16 |          |  |        |        |         |         |